

INSTALLATION INSTRUCTIO

As illustrated below, this kit consists of:

Tail Light Assembly Qty: 1 Self-tapping screws Qty: 2 Bracket Qty: 1 Bolt M5 Qty: 2 Nut M5 Qty: 2 Washer M5 Qty: 2





TAIL LIGHT KIT (15914)

This kit is ONLY used on 2014 and newer 200 series LUTVs







- Locate the dimples on the underside of the bed near the center. Drill 1/8" hole in each dimple, being careful not to drill through the top side of the bed.
- Position the tail light so the tail light bracket holes line up with the previously drilled holes in the bed.
- Use the self tapping screws to anchor the tail light bracket to the bed as shown in figure 1.
- Mount the tail light to the bracket using the M5 bolts, nuts and washers.
- Plug the tail light into the matching harness plug near the electrical box under the bed as shown in figure 2.



