




YELLOW JACKET

DK6 5506

1. 5406-20	FRAME - YELLOW	78. 8219	JACKSHAFT	116. 5411-2	CROSS BAR
5406-5	FRAME - RED	79. 3403	KEY 3/16 SQ. X 2"	117. 5447	SAFTY FLAG
ASM 5431	TIE ROD ASM (2-6)	80. 1119	SPACER 5/8 ID	118. 9188	BOLT 1/2-13 X 1-1/2
2. 5430	TIE ROD 14"	81. 1125S	SPROCKET 420P 9T	119. 6958	DECAL T/PRESS
3. 9092	NUT, 3/8-24 HEX JAM	82. 1031	KEY 3/16 SQ. X 1/2	120. 8138	DECAL L/HAIR
4. 1414	TIE ROD END, RH	ASM. 5958	DRIVEN PULLEY (83-89)	121. 4912	DECAL WARNING
5. 1415	TIE ROD END, LH	83. *	STAY / SHEAVE	122. 1049	DECAL DR. COVER
6. 9024	NUT, 3/8-24 LH JAM	84. 200349	BUSHING	123. 9929	RUBBER CAP
7. 9145	BOLT, 3/8-16 X 1-3/4	85. *	MOVEABLE / SHEAVE	124. 6573	BOLT 5/16 - 18 X 1-3/4
8. 6123	KEY, 1/4-SQ. X 3/4	86. *	BUCTION NYLON	125. 8826	LOOP CLIP
9. 9146	BOLT, 3/8 - 16 X 1-1/2	87. *	SPRING	126. 5412	1/2 SHAFTSUPT RH
10. 2457	SPINDLE, RH	88. *	CAM	127. 5413	1/2 SHAFT SUPT LH
NI 2458	SPINDLE, LH	89. *	RETAINING RING	128. 2386	BOLT 3/8 - 16 X 3-1/2
11. 1264	BOLT 1/2 X 13 X 3-3/4	90. 5959	BEELT	129. 5762	SPACER 3/8 ODX 1"
12. 1012	NUT 1/2-13 T/LOCK	91. 8227	NUT (CLIP)	130. 5415	ROD END STAB.
13. 5157	SPACER 5/8 IDX 3/4	92. 5526	TOP COVER	131. 1449	BOLT 3/8-16 X 2.00
14. 1466	NUT 5/8-11 FLEX/LOCK	93. 5527	LH COVER	132. 1264	BOLT 1/2 X 3-3/4
ASM. 9309 FP	WHEEL ASM (15-17)	94. 5528	RH COVER	133. 9158	BOLT 3/8-16 X 2-1/2
15. 5090	BEARING 5/8ID1-3/8	95. 10293	MOUNT. STRAP	134. 5584	DIPSTICK
16. 5950	SPANNER	96. 6511	CHAIN	135. 5585	FILL TUBE
17. 4915	TIRE 145/70 X 6	97. 9679	DECAL NO RIDERS	NI 5586	O-RING, FILL TUBE
18. 3802	TUBE (REPAIR PART)	98. 9677	DECAL W/ O OIL	NI 5587	CLIP, FILL TUBE
19. G0850	LOOM 8.5" X 3"	99. 5964	DECAL ENG/ EXH	NI 5405	DECAL Y J 8"
ASM. 5428	RE WHEEL ASM, (20,21A)	100. 9678	ENGINE 6.0	NI 4504	DECAL WARNING
20. 3548	TIRE 18/9.5 X 8	101. 5533	BOLT 5/16-24X1- 3/4	NI 6540	DECAL HELMET
21. 1430	TUBE (REPAIR PART)	102. 1454	WASHER 5/16 SL	NI 8154	DECAL NO CHILD
21.A 10324	RIM 8" (REPAIR PART)	103. 1124	WASHER 5/16 FLAT	NI 2832	DECAL NO PASS
22. 54165	CENTER SHAFT	ASM. 5957	DRIVER (105-110)		
23. 54172	OUTER SHAFT	105. *	DRUM	MANUALS NOT SHOWN	
ASM. 6420	SPROCKET ASM (24-27)	106. *	HUB	OPERATORS MANUAL	
24. 6282	SPROCKET 54T	107. *	SHOE ASSEMBLY	ADDENDUM OM BRAKE	
25. 6280	SPROCKET HUB	108. *	MOVEABLE / SHEAVE	AND TAV	
26. 6701	BOLT 5/16 - 18 X 1-1/4	109. *	BUSHING	ADDEM OM SEATBELTS	
27. 9006	BOLT 1/2-20 X 1/2 WF	110. *	STATIONARY / SHEAVE	FOAM PACK	
28. 2417	BRAKE DRUM	111. 1938	SPACER 3/4 X 3/8	9283R3	
29. 3712	KEY 1/4 SQ. X 1"	112. 5408-2	OVERHEAD BARLH	10042	
30. 2513	BRAKE BAND	113. 5409-2	OVERHEAD BARRH		
31. 9118	PIN CLEVIS	114. 5461	SEAT BELT	ASM =	ASSEMBLY
32. 9091	WASHER FLAT 3/8	115. 9022	WASHER 1/2 FLAT	NI =	NOT ILLUSTRATED
33. 9116	PIN COTTER			*	NOT SOLD SEPARATELY
34. 5523	U-JOINT				
NI. 10390	U-JOINT REPAIR KIT				
35. 1775	KEY 1/4 SQ. X 1-1/2"				
36. 9127	BOLT 5/16-18X 2-1/4				
37. 1139	NUTS/16-18 T/LOCK				
38. 5414	BEARING 1" ID 2"				

